

DragonFire Racing

2330 W. Broadway Rd #112

Mesa, AZ 85202

1 (800) 708-9803

WWW.DRAGONFIRERACING.COM



FEEL THE HEAT!

Wild Cat RacePace Rear Bumper Installation Instructions

Congratulations on your purchase of the new Wild Cat RacePace rear bumper.

Built with simplicity in mind this lightweight tube bumper drops right into place and installs in a snap. Giving great looks as well as rear end protection for your crucial parts such as the exhaust and gas tank.

Disclaimer

Off road activities can be hazardous and could lead to injury, dismemberment, paralysis and death. No warranty of representation is made as to the products ability to protect the user from any injury or death. The user assumes that risk. The acceptance and /or use of this merchandise purchased from DragonFire by the customer hereby shall release DragonFire from any and all liability pertaining to the use of such merchandise.

Tools Required

3/16" Wrench

1/2" Wrench

T20 Torx Bit

5/16" Socket

1/4" Extension

1/4" Ratchet

Reciprocating Saw



- Do not use if there is any sign of damage or fatigue
- This bumper is not designed to protect against rear end collision
- Do not use this bumper to push or pull other vehicles
- Will increase overall vehicle length

Step 1: Place vehicle on flat and level surface. Place gear selector in “park” and remove keys from the ignition.

Step 2: Install rear bumper by holding it up to rear end of UTV and inserting the bent over tabs on bumper through tri-angle cutout in the rear. Let bumper settle down into place and ensure that both tabs are holding bumper firmly to frame of UTV.

(See Figure A)



Dragonfire Racing

Step 3: Secure bumper with supplied hardware using 3/16" Allen Wrench & 1/2" Wrench. (See Figure B)



Step 4: Install bumper end caps by pressing into place with hand. (See Figure C)



Step 5: Remove factory exhaust heat shield by removing all six Torx screws from end cap of exhaust. Set aside these will be re-used. (See figure D)



Step 6: Cut factory exhaust tip off using reciprocating saw. Make sure to leave 3/4" of factory pipe. (See figures E & F)



Step 7: Slide new supplied exhaust tip onto rear of exhaust and secure with hose clamp. Be sure to angle exhaust tip away from bumper tubes. (See figure G)



Step 8: Re-install factory exhaust heat shield using hardware retained in Step 5. (See figure H)



*Pro Tip: Be sure to check hardware regularly and re-tighten if needed

For further assistance please contact your authorized DragonFire dealer



Dragonfire Racing