

DragonFire Racing

2330 W. Broadway Rd #112

Mesa, AZ 85202

1 (800) 708-9803

WWW.DRAGONFIRERACING.COM



FEEL THE HEAT!

RacePace Dash Bar Installation Instructions

Congratulations on your purchase of the Race Pace Dash Bar. As part of our Race Pace modular cage system the Dash Bar will provide added support and aggressive styling to any RZR. The Dash Bar is simple to install and looks great!

! WARNING

- *Do not use product if there is any sign of damage
- *Frequently check all hardware to ensure everything is secure
- *This product may inhibit line of sight in some instances
- *Replacement may be required in the event of roll over

Disclaimer

Off road activities can be hazardous and could lead to injury, dismemberment, paralysis and death. No warranty of representation is made as to the products ability to protect the user from any injury or death. The user assumes that risk. The acceptance and /or use of this merchandise purchased from DragonFire by the customer hereby shall release DragonFire from any and all liability pertaining to the use of such merchandise.

Tools Required
3/16 Allen Wrench
5/16 Allen Wrench

Step 1: Remove all pieces from packaging, make sure that all pieces are accounted for and not damaged. (If there is missing or damaged product please contact your authorized DragonFire dealer)

Step 2: Remove both bolts and nuts from front lower cage bung on driver side using 5/16 Allen wrench. This will allow for more clearance during install.

Step 3: Remove all six bolts and top piece of cage clamp from both cage clamps (A&B) using a 3/16 Allen wrench.



Dragonfire Racing

Step 4: Place Dash Bar inside front portion of cage. Make sure that the bend is in a downward manner and that the bar is evenly spaced from dash of UTV.

Step 5: Re-Install both bolts and nuts into front lower cage bung on driver side of UTV using 5/16 Allen wrench. ***Check owner's manual for proper torque specifications.***

Step 6: Re-Install top piece and all six bolts to both cage clamps using 3/16 Allen wrench. Evenly tighten each bolt until snug (**7 Foot Pounds Torque**). Installation is now complete.

PRO Tip:

Regularly check each bolt on Dash Bar to ensure that they are snug.

For further assistance please contact your authorized DragonFire dealer.



Dragonfire Racing