

DragonFire Racing

2330 W. Broadway Rd #112

Mesa, AZ 85202

1 (800) 708-9803

WWW.DRAGONFIRERACING.COM



FEEL THE HEAT!

Wild Cat Debris Shields Installation Instructions

Congratulations on your purchase of the new Wild Cat Debris Shields; designed to add protection to the plastic wheel well and floor board of your Wild Cat. Integrated built in side scoops keep the factory oil cooler running smooth. These are by far some of the best protection money can buy for your Wild Cat.

Tools Required

7/16" Wrench

5/32" Allan Wrench

T30 Torx bit

Disclaimer

Off road activities can be hazardous and could lead to injury, dismemberment, paralysis and death. No warranty of representation is made as to the products ability to protect the user from any injury or death. The user assumes that risk. The acceptance and /or use of this merchandise purchased from DragonFire by the customer hereby shall release DragonFire from any and all liability pertaining to the use of such merchandise.



- Do not use if there is any sign of damage or fatigue
- This product is not designed to protect against front end collision
- Not guaranteed to protect vehicle occupants

Step 1: Place vehicle on flat and level surface. Place gear selector in "Park" and remove keys from the ignition.

Step 2: Using supplied hardware attach scoop panel to large panel for both sides of vehicle. (See Figure A)



Step 3: Remove four factory bolts from wheel well/fire wall plastics. Retain this hardware they will be re-used. (See Figure B)



Dragonfire Racing

Step 4: Place debris shield assembly up to car and retain with hardware that was removed in Step 2. **(See Figure C)**



Step 5: Place supplied P-clamp around frame tube located near the bottom corner of debris shield scoop panel. Retain the corner of scoop using supplied hardware and P-clamp. **(See Figure D)**

*Pro Tip: Be sure to check hardware regularly and re-tighten if needed

For further assistance please contact your authorized DragonFire dealer



Dragonfire Racing